

1002/108, 13004




Figure 1




Figure 2




Figure 3

10007108 120004




Figure 4

10027108.120001




FIGURE 5

10037108.12001




Figure 6

A perspective view of a portable electronic device 10, such as a portable music player. The device features a display 120 and a speaker 126. It is shown with a carrying case 130 and a base 134. A power cord 135 is connected to the device. The device is labeled 16.

Figure 7

78




Figure 8

10067108-13001

1003408-120004




Figure 9

Figure 10.